

TEXIO
Test and Measurement Solutions

PROGRAMMING MANUAL

DIGITAL STORAGE OSCILLOSCOPE DCS-4605



B71-0394-01

■ About a trademark, a registered trademark

A company name and the brand name mentioned in this instruction manual are the trademark or the registered trademark of each company or group in each country and region.

■ About this instruction manual

When copying the part or all of contents of this instruction manual, seek the copyright holder.

In addition, the specifications of the product and the contents of this instruction manual are subject to change without notice for improvement. Please check to our website for the latest version.

CONTENTS

1. INTERFACE OVERVIEW	1
1-1. Rear Panel Overview.....	1
1-2. Configuring the USB Interface.....	1
2. COMMAND OVERVIEW	3
2-1. Command Syntax	3
3. COMMAND DETAILS	4
3-1. System Command	5
3-1-1. *IDN	5
3-1-2. *LRN	6
3-1-3. *RST	6
3-1-4. :SYSTem:ERRor	7
3-1-5. SYSTem:VERSion	7
3-2. Acquisition Command	8
3-2-1. :ACQuire:AVERage	8
3-2-2. :ACQuire:MODE	9
3-2-3. :ACQuire<X>:MEMORY	9
3-3. Autoset Command	10
3-3-1. :AUToset.....	10
3-4. Channel / Math Command	11
3-4-1. :CHANnel<X>:BWLimit	11
3-4-2. :CHANnel<X>:COUPLing	12
3-4-3. :CHANnel<X>:DISPlay	12
3-4-4. :CHANnel<X>:INVert	13
3-4-5. :CHANnel<X>:MATH	13
3-4-6. :CHANnel<X>:OFFSet	14
3-4-7. :CHANnel<X>:PROBe	15
3-4-8. :CHANnel<X>:SCALe	15
3-5. Math Command	16
3-5-1. :MATH:OPERator	16
3-5-2. :MATH:POSition.....	17
3-5-3. :MATH:FFT:SOURce	17
3-5-4. :MATH:FFT:WINDOW	18
3-5-5. :MATH:FFT:SCALe	18
3-6. Cursor Command	19
3-6-1. :CURSor:X<X>Position.....	19
3-6-2. :CURSor:Y<X>Position.....	20
3-6-3. :CURSor:<X>DELta	21
3-6-4. :CURSor:<X>DISPLAY	22
3-6-5. :CURSor:SOURce	22
3-7. Display Command	23
3-7-1. :DISPlay:ACCumulate.....	23


3-7-2. :DISPlay:CONTrast.....	24
3-7-3. :DISPlay:GRATicule.....	24
3-7-4. :DISPlay:WAVeform.....	25
3-7-5. :REFResh	25
3-8. Measure Command	26
3-8-1. :MEASure:FALL.....	27
3-8-2. :MEASure:FOVShoot.....	27
3-8-3. :MEASure:FPReShoot.....	28
3-8-4. :MEASure:FREQuency	28
3-8-5. :MEASure:NWIDth.....	29
3-8-6. :MEASure:PDUTy	29
3-8-7. :MEASure:PERiod	30
3-8-8. :MEASure:PWIth	30
3-8-9. :MEASure:RISe.....	31
3-8-10. :MEASURE:ROVShoot	31
3-8-11. :MEASURE:RPReShoot	32
3-8-12. :MEASURE:SOURce	32
3-8-13. :MEASURE:VAMPtitude	33
3-8-14. :MEASURE:VAverage	33
3-8-15. :MEASURE:VHI.....	34
3-8-16. :MEASURE:VLO	34
3-8-17. :MEASURE:VMAX	35
3-8-18. :MEASURE:VMIN.....	35
3-8-19. :MEASURE:VPP	36
3-8-20. :MEASURE:VRMS	36
3-9. Go No-Go Command	37
3-9-1. :GONogo:CLEAR.....	37
3-9-2. :GONogo:EXECute	38
3-9-3. :GONogo:FUNCtion	38
3-9-4. :GONogo:NGCount?	39
3-9-5. :GONogo:NGDefine	39
3-9-6. :GONogo:SOURce	40
3-9-7. :GONogo:VIOLation	40
3-9-8. :TEMPPlate:MODe	41
3-9-9. :TEMPPlate:MAX	42
3-9-10. :TEMPPlate:MIN.....	43
3-9-11. :TEMPPlate:POSition:MAX	44
3-9-12. :TEMPPlate:POSition:MIN	45
3-9-13. :TEMPPlate:SAVE:MAXimum	46
3-9-14. :TEMPPlate:SAVE:MINimum	46
3-9-15. :TEMPPlate:TOLERance	47
3-9-16. :TEMPPlate:SAVE:AUTO.....	48
3-10. Data Logging Command	49
3-10-1. :DATALOG:STATE	49
3-10-2. :DATALOG:SOURce	49
3-10-3. :DATALOG:SAVE	50
3-10-4. :DATALOG:INTerval	50

3-10-5. :DATALOG:DURation	51
3-11. Save/Recall Command	52
3-11-1. :MEMORY<X>:RECall:SETup	52
3-11-2. :MEMORY<X>:RECall:WAVeform	53
3-11-3. :MEMORY<X>:SAVe:SETup	53
3-11-4. :MEMORY<X>:SAVe:WAVeform	54
3-11-5. *RCL	54
3-11-6. :REF<X>:DISPlay	55
3-11-7. :REF<X>:LOCate	55
3-11-8. :REF<X>:SAVe	56
3-11-9. *SAV	56
3-12. Time (Horizontal) Command	57
3-12-1. :TIMEbase:DELay	57
3-12-2. :TIMEbase:SCALE	58
3-12-3. :TIMEbase:SWEep	59
3-12-4. :TIMEbase:WINDOW:DELay	59
3-12-5. :TIMEbase:WINDOW:SCALE	60
3-13. Trigger Command	61
3-13-1. :FORCe	61
3-13-2. :RUN	61
3-13-3. :SINGle	62
3-13-4. :STOP	62
3-13-5. *TRG	62
3-13-6. :TRIGger:COUPle	63
3-13-7. :TRIGger:FREQuency	63
3-13-8. :TRIGger:LEVel	64
3-13-9. :TRIGger:MODE	64
3-13-10. :TRIGger:NREJ	65
3-13-11. :TRIGger:PULSe:MODE	65
3-13-12. :TRIGger:PULSe:TIME	66
3-13-13. :TRIGger:REject	66
3-13-14. :TRIGger:SLOPe	67
3-13-15. :TRIGger:STATe	68
3-13-16. :TRIGger:SOURCE	69
3-13-17. :TRIGger:TYPE	69
3-13-18. :TRIGger:VIDeo:FIELD	70
3-13-19. :TRIGger:VIDeo:LINE	71
3-13-20. :TRIGger:VIDeo:POLarity	72
3-13-21. :TRIGger:VIDeo:TYPE	72

1.INTERFACE OVERVIEW

This manual describes how to use the DCS-4605's remote command functionality and lists the command details. The Overview chapter describes how to configure the DCS-4605 USB remote control interface.

1-1.Rear Panel Overview



1-2.Configuring the USB Interface

USB connection	PC side connector	Type A, host
	DCS-4605 side connector	Type B, device
Speed	1.1/2.0 (full speed)	

USB driver OS Microsoft Windows 7 or higher
software File name TEXIO_CDC.inf (Attached CD)

! CAUTION: DCS-4605 is allocated to the COM port when installing it. The set is recognized as a serial communications equipment on PC. You must have administrator account to install.
Serial port setting: Speed 12Mbps or less

Data-bits : 8 bit
Parity : none
Stop-bit : 1 bit
Flow-control : none

- Panel operation 1. Connect the USB cable to the USB device port on the rear.
- 
2. When the PC asks for the USB driver or 'Unknown device' listed in Device Manager, install TEXIO-CDC.inf attached CD.
 3. On the PC, activate a terminal application such as PuTTY. To check the COM port No., see the Device Manager in the PC.
 4. Run this query command via the terminal application.
*idn?
This command should return the manufacturer, model number, serial number, and firmware version in the following format.
TEXIO, DCS-4605, XXXXXX, V1.00
 5. Configuring the command interface is completed. Refer to the other chapters for more details.


! CAUTION: If there is no response, please confirm a driver software, COM port number or the connection of the cable and so on.

! CAUTION: If you change the setting of the USB port in the connection with the PC, May not be able to communicate. Please restart your PC in this case.

2.COMMAND OVERVIEW

The command syntax section shows you the basic syntax rules you have to apply when using commands.

2-1.Command Syntax

Compatible standard	<ul style="list-style-type: none">• USB CDC_ACM compatible• SCPI, 1994 (partially compatible)																		
Command format	trig:del:mod <NR1>LF  <p>1: command header 2: single space 3: parameter 4: message terminator</p>																		
Parameter	<table><thead><tr><th>Type</th><th>Description</th><th>Example</th></tr></thead><tbody><tr><td><Boolean></td><td>boolean logic</td><td>0, 1</td></tr><tr><td><NR1></td><td>Integers</td><td>0, 1, 2, 3</td></tr><tr><td><NR2></td><td>decimal numbers</td><td>0.1, 3.14, 8.5</td></tr><tr><td><NR3></td><td>floating point</td><td>4.5e-1, 8.25e+1</td></tr><tr><td><NRf></td><td>any of NR1, 2, 3</td><td>1, 1.5, 4.5e-1</td></tr></tbody></table>	Type	Description	Example	<Boolean>	boolean logic	0, 1	<NR1>	Integers	0, 1, 2, 3	<NR2>	decimal numbers	0.1, 3.14, 8.5	<NR3>	floating point	4.5e-1, 8.25e+1	<NRf>	any of NR1, 2, 3	1, 1.5, 4.5e-1
Type	Description	Example																	
<Boolean>	boolean logic	0, 1																	
<NR1>	Integers	0, 1, 2, 3																	
<NR2>	decimal numbers	0.1, 3.14, 8.5																	
<NR3>	floating point	4.5e-1, 8.25e+1																	
<NRf>	any of NR1, 2, 3	1, 1.5, 4.5e-1																	
Message terminator	<table><tbody><tr><td>LF^END</td><td>line feed code (hexadecimal 0A) with END message</td></tr><tr><td>LF</td><td>line feed code</td></tr><tr><td><dab>^END</td><td>last data byte with END message</td></tr></tbody></table>	LF^END	line feed code (hexadecimal 0A) with END message	LF	line feed code	<dab>^END	last data byte with END message												
LF^END	line feed code (hexadecimal 0A) with END message																		
LF	line feed code																		
<dab>^END	last data byte with END message																		



CAUTION:

- Commands are non-case sensitive.
- On the real input of the value to the parameter, please do not use the symbol as "<", ">", "|".
The above symbols are used to facilitate distinction with this manual.

3.COMMAND DETAILS

3-1. System Command	5
3-2. Acquisition Command	8
3-3. Autoset Command	10
3-4. Channel / Math Command	11
3-5. Math Command.....	16
3-6. Cursor Command	19
3-7. Display Command	23
3-8. Measure Command	26
3-9. Go No-Go Command	37
3-10. Data Logging Command	49
3-11. Save/Recall Command.....	52
3-12. Time (Horizontal) Command.....	57
3-13. Trigger Command	61

3-1.System Command

3-1-1. *IDN	5
3-1-2. *LRN	6
3-1-3. *RST	6
3-1-4. :SYSTem:ERRor	7
3-1-5. SYSTem:VERSion	7

A kind of Query or Set is → **Query** : Query
shown.

Set → : Set

3-1-1.*IDN

→ Query

Description	Returns the oscilloscope ID: manufacturer, model name, serial number, and firmware version. Same as: Utility key → F4	
Syntax	*idn?	
Example	*idn? TEXIO, DCS-4605, XXXXXXX, V1.00	Returns the ID for a DCS-4605.

3-1-2.*LRN

→ **Query**

Description	Returns the oscilloscope settings as a data string.
Syntax	*Irn?
Example	*Irn? :DISPlay:WAveform 0;ACCumulate 0;CONTrast 0;GRATicule 0;;CHANnel1:DISPlay 1;BWLimit 0;COUpling 0;INVert 0;OFFSet 2.000e+00;PROBe 3;SCALe 2.000e+00;;CHANnel2:DISPlay 1;BWLimit 0;COUpling 0;INVert 0;OFFSet 2.000e+00;PROBe 3;SCALe 2.000e+00;;CHANnel1:MATH 0;;TIMEbase:SWEep 0;SCALe 2.500e-06;DELay 0.000e+00;WINDOW:SCALe 2.50000e-07;DELay 0.00000e+00;;ACQuire:MODE 0;AVERage 0;;TRIGger:TYPE 0;SOURce 0;MODE 1;SLOP 0;COUPle 1;REject 0;NREJ 0;LEVEL 0.00000e+00;PULSe:MODE: 0;TIME 0.00000e+00;;VIDeo:TYPE 1;POLarity 0;FIELD 0;LINE 0;;CURSor:SOURce 1;XDISPlay 0;X1Position 75;X2Position 175;YDISPlay 0;Y1Position 54;Y2Position 154;;REF1:DISPlay 0;LOCate 50;;REF2:DISPlay 0;LOCate -50;;RUN

3-1-3.*rst

→ **Set**

Description	Resets the DCS-4605 (recalls the default panel settings).
	Same as: Save/Recall key → F1
Syntax	*rst
 CAUTION:	In the help mode (the screen display of the function explanation), the command is invalid.
 CAUTION:	The saved content in the internal memory is not initialized by the recall function of “Default Setup”.

3-1-4.:SYSTem:ERRor

→(Query)

Description	Returns the oscilloscope system error message, if there is any.			
Syntax	< Long > :system:error?		< Short > :syst:err?	
Parameter	ID	Contents	ID	Contents
	-100	command error	-102	syntax error
	-220	parameter error	-221	settings conflict
	-222	data out of range	-223	too much data
	-224	illegal parameter	-232	invalid format
Example	:system:error? -102		Indicates that the command syntax is wrong.	
:				

3-1-5.SYSTem:VERSion


→(Query)

Description	Returns the SCPI version to which the oscilloscope complies to. This is returned as the SCPI version year and revision number (YYYY.V).		
Syntax	< Long > :system:version?		< Short > :syst:vers?
Example	:syst:vers? 1992.0		Returns the SCPI version as 1992.0

3-2.Acquisition Command

3-2-1. :ACQuire:AVERage	8
3-2-2. :ACQuire:MODe	9
3-2-3. :ACQuire<X>:MEMory	9

3-2-1.:ACQuire:AVERage



Description Selects or returns the average number of waveform acquisition in the average acquisition mode.

Same as: Acquire key → F2


Syntax	< Long >	< Short >
	:acquire:average <NR1>	:acq:aver <NR1>
	:acquire:average?	:acq:aver?

Parameter	<NR1>	Average No.	<NR1>	Average No.
	1	2	5	32
	2	4	6	64
	3	8	7	128
	4	16	8	256

CAUTION: Before using this command, select the average acquisition mode. See the example below.

Example	:acquire:mode 2	Selects the average acquisition mode,
	:acquire:average 2	and select the average number 4.

3-2-2.:ACQuire:MODE



Description	Selects or returns the acquisition mode. Same as: Acquire key → F1 ~ F3			
Syntax	< Long > < Short > :acquire:mode <NR1> :acq:mod <NR1> :acquire:mode? :acq:mod?			
Parameter	<NR1>	Mode	<NR1>	Mode
	0	Normal	2	Average
1	Peak detect			
Example	:acquire:mode 2 :acquire:average 2	Selects the average acquisition mode, and select the average number 4.		

3-2-3.:ACQuire<X>:MEMory



Description	Returns the total waveform data in the acquisition memory.			
Syntax	< Long > < Short > :acquire<X>:memory? :acq<X>:mem?			
Parameter	<X>	Channel		
	1/2	Channel1/2		
Example	:acquire1:memory?	Returns the channel 1 waveform data.		
Data format	Six data elements are concatenated to form one data string. # A B C D E F A: Data size digit B: Data size C: Time interval D: Channel indicator E: Reserved data F: Waveform data # (1 byte) The start of data transfer. The value is 0X23 ("#" in ASCII code). Data size digit (1 bytes) Indicates the number of digits used for the data string that follows. The data size digit is always 4.			

Data size (4 bytes)

Indicates the data size. The data size is always 8008 (4000 points per channel).

8 bytes are total of Time interval, Channel indicator, and Reserved data.

Time interval (4 bytes)

Indicates the time interval between two adjacent sampling points in the floating point format, compatible with IEEE 754 standards.

Note: The data is sorted in the little-endian format.

Channel indicator (1 byte)

Indicates the channel. 1 (0X01) or 2 (0X02).

Reserved data (3 bytes)

An unused data block, 3 bytes.

Waveform data (8000 bytes)

The waveform data comprised of 4000 data points.

Each point is made up of 2 bytes (16 bits), two's complement, high byte (MSB) first.

Example

Data size digit(4) Time interval(0X31 09 70 5F)

Data size(8008) Channel indicator(0X01)

Reserved data

000000 23 34 38 30 30 38 31 09-70 5F 01 08 7E 7E FF E5 #480081.p_.. ~~ .
000010 FF E5 FF E5 FF E5 FF E5-FF E5 FF E5 FF E5 FF E5 FF E6
000020 FF E5 FF F5 FF F4 FF F4-FF F4 FF F5 FF F5 FF F5

10000000 11 20 11 20 11 21 11 21 11 21 11 20 11 21 11 20

Waveform data after this(FF)

3-3.Autoset Command

3-3-1.:AUToset




Description	Runs the Autoset function to automatically configure the horizontal scale, vertical scale, and trigger according to the input signal. Same as: Auto Set key
Syntax	< Long > :autoset < Short > :aut

3-4.Channel / Math Command

3-4-1. :CHANnel<X>:BWLimit	11
3-4-2. :CHANnel<X>:COUPling	12
3-4-3. :CHANnel<X>:DISPlay	12
3-4-4. :CHANnel<X>:INVert	13
3-4-5. :CHANnel<X>:MATH	13
3-4-6. :CHANnel<X>:OFFSet	14
3-4-7. :CHANnel<X>:PROBe	15
3-4-8. :CHANnel<X>:SCALe	15

3-4-1.:CHANnel<X>:BWLimit



Description Selects or returns the bandwidth limit on/off.


Same as: Channel key → F3

Syntax	< Long >	< Short >
	:channel<X>:bwlimit <Boolean>	:chan<X>:bwl <Boolean>
	:channel<X>:bwlimit?	:chan:bwl?

Parameter	<X>	Channel	<NR1>	Limit
	1/2	CH1/2	0	Off


Example :channel1:bwlimit 1 Turns on the bandwidth limit for Channel 1.

3-4-2.:CHANnel<X>:COUPling




Description	Selects or returns the coupling mode. Same as: Channel key → F1			
Syntax	< Long > :channel<X>:coupling <NR1> :channel<X>:coupling? < Short > :chan<X>:coup <NR1> :chan:coup?			
Parameter	<X> 1/2	Channel CH1/2	<NR1> 0 1 2	Coupling mode AC coupling DC coupling Ground coupling
Example	:channel1:coupling 1 Selects the DC coupling for Channel 1.			

3-4-3.:CHANnel<X>:DISPlay




Description	Turns a channel on/off or returns its status. Same as: Channel key			
Syntax	< Long > :channel<X>:display <Boolean> :channel<X>:display? < Short > :chan<X>:disp <Boolean> :chan<X>:disp?			
Parameter	<X> 1/2	Channel CH1/2	<NR1> 0 1	Channel on/off Off On
Example	:channel1:display 1 Turns on Channel 1.			

3-4-4.:CHANnel<X>:INVert




Description	Inverts a channel or returns its status. Same as: Channel key → F2			
Syntax	< Long > < Short > :channel<X>:invert <Boolean> :chan<X>:inv :channel<X>:invert? <Boolean> :chan<X>:inv?			
Parameter	<X> 1/2	Channel CH1/2	<NR1> 0 1	Channel invert Off On
Example	:channel1:invert 1 Inverts Channel 1.			

3-4-5.:CHANnel<X>:MATH



Description	Selects or returns the math operation type. Same as: Math key → F1			
Syntax	< Long > < Short > :channel<X>:math <NR1> :chan<X>:math <NR1> :channel<X>:math? :chan<X>:math?			
Parameter	<X> 1/2	Channel CH1 or CH2	<NR1> 0 1 2 3	Math operation Math off Add Subtract FFT
Example1	:channel1:math 2 Channel 1 – Channel 2			
Example2	:channel2:math 2 Channel 2 – Channel 1			
Example3	:channel2:math 3 Runs FFT on Channel 2			


3-4-6.:CHANnel<X>:OFFSet



Description	Sets or returns the offset level for a channel. The offset level range depends on the vertical scale. Unit: V			
Syntax	< Long > :channel<X>:offset <NR3> < Short > :channel<X>:offset? :chan<X>:offs <NR3> :channel<X>:offset? :chan<X>:offs?			
Parameter	<X> 1/2	Channel CH1/2	<NR3> ±0.4 ±4 ±40 ±300	Offset level ±0.4V (2mV/div~20mV/div) ±4V (50mV/div~200mV/div) ±40V (500mV/div~2V/div) ±300V (5V/div~10V/div)
Example	:channel1:scale 1.00e-2 :channel1:offset 2.00e-2			


Sets the Channel 1 scale to 10mV/div.
Sets the Channel 1 offset to 20mV.

3-4-7.:CHANnel<X>:PROBe



Description	Sets or returns the probe attenuation factor. Same as: Channel key → F4			
Syntax	< Long > :channel<X>:probe<NR1> :channel<X>:probe? < Short > :chan<X>:prob<NR1> :chan<X>:prob?			
Parameter	<X>	Channel	<NR1>	Probe attenuation factor
	1/2	CH1/2	0	1x
			1	10x
			2	100x
Example	:channel1:probe 1		Sets the Channel 1 probe attenuation factor to 10x.	

3-4-8.:CHANnel<X>:SCALE




Description	Sets or returns the vertical scale. The scale depends on the probe attenuation factor. Same as: Volts/Div knob Unit: V/div			
Syntax	< Long > :channel<X>:scale <NR3> :channel<X>:scale? < Short > :chan<X>:scal <NR3> :chan<X>:scal?			
Parameter	<X>	Channel	<NR3>	Vertical scale
	1/2	CH1/2	2e-3 ~ 1e+1	2mV ~ 10V (Probe x1)
			2e-2 ~ 1e+2	20mV ~ 100V (Probe x10)
			2e-1 ~ 1e+3	200mV ~ 1000V (Probe x100)
Example	:channel1:probe 0 :channel1:scale 2.00e-3		Sets the Channel 1 probe attenuation factor to x1. Sets the Channel 1 vertical scale to 2mV/div.	

3-5.Math Command


3-5-1. :MATH:OPERator	16
3-5-2. :MATH:POSition.....	17
3-5-3. :MATH:FFT:SOURCE	17
3-5-4. :MATH:FFT:WINDOW	18
3-5-5. :MATH:FFT:SCALe	18

3-5-1.:MATH:OPERator




Description	Sets the math operator.			
Syntax	< Long >		< Short >	
	:MATH:OPERator {0 1 2} :MATH:OPER {0 1 2}			
	:MATH:OPERator?		:MATH:OPER?	
Parameter	0	Addition	1	Subtraction
	2	FFT		
Example	:MATH:OPER 0	Sets the operator to addition.		

3-5-2.:MATH:POSIon




Description	Sets or vertical position (in grid divisions) of the math output waveform.	
Syntax	< Long >	< Short >
	:MATH:POSIon <NR3>	:MATH:POS <NR3>
	:MATH:POSIon?	:MATH:POS?
Parameters	<NR3> -12.00 ~ +12.00, with 0.00 being the center division.	
Example	:MATH:POS 3.00	Sets the position to the 3 rd division above the center division.

3-5-3.:MATH:FFT:SOURce




Description	Sets the source channel for FFT math.	
Syntax	< Long >	< Short >
	:MATH:FFT:SOURce {1 2}	:MATH:FFT:SOUR {1 2}
	:MATH:FFT:SOURce?	:MATH:FFT:SOUR?
Parameters	1	Channel 1
	2	Channel 2
Example	:MATH:FFT:SOUR 1 Sets the source to CH1	

3-5-4.:MATH:FFT:WINDOW



Description	Sets FFT window type.		
Syntax	< Long >	< Short >	
	:MATH:FFT:WINDOW {0 1 2 3}	:MATH:FFT:WIND {0 1 2 3}	
Parameters	0	Hanning window	
	1	Flattop window	
	2	Rectangular window	
	3	Blackman window	
Example	:MATH:FFT:WIND 0	Sets the window type to Hanning.	

3-5-5.:MATH:FFT:SCALe




Description	Sets the FFT scale in dB.			
Syntax	< Long >		< Short >	
	:MATH:FFT:SCALe {20 10 5 2 1}		:MATH:FFT:SCAL {20 10 5 2 1}	
Parameters	20	20 dB	2	2 dB
	10	10 dB	1	1 dB
	5	5 dB		
Example	:MATH:FFT:SCAL 5	Sets the vertical scale to 5 dB.		

3-6.Cursor Command


3-6-1. :CURSor:X<X>Position	19
3-6-2. :CURSor:Y<X>Position	20
3-6-3. :CURSor:<X>DELta	21
3-6-4. :CURSor:<X>DISplay	22
3-6-5. :CURSor:SOURce	22

3-6-1.:CURSor:X<X>Position



Description	Sets or returns the horizontal (X axis) cursor position. Same as: Cursor key → F5 (X-Y) →F2 (X1) or F3 (X2) + Variable knob			
Syntax	< Long > < Short > :cursor:x<X>position <NR1> :curs:x<X>p <NR1> :cursor:x<X>position? :curs:x<X>p?			
Parameter	<X>	Cursor 1 or 2	<NR1>	Cursor position
CAUTION: The set data format is <NR1> as follows. 1:0div(Left),125:5div(Center),249:10div(Right)				
CAUTION:		The returned data format is <NR3> as follows. CH1, CH2, Math(CH1±CH2): time (s) Math (FFT): frequency (Hz)		
Example	:cursor:xdisplay 1	Puts the horizontal cursor		
	:cursor:x1position 125	X1 on the center position.		
	:channel:math 3	Returns the X1 cursor		
	:cursor:xdisplay 1	position as 2500Hz in the		
	:cursor:x1position?	Math FFT mode.		
	→ 2.500E+03			

3-6-2.:CURSor:Y<X>Position



Description	Selects or returns the vertical (Y axis) cursor position. Same as: Cursor key → F5 (X-Y) → F2(Y1) or F3(Y2) + Vertical knob			
Syntax	< Long > < Short > :cursor:y<X>position <NR1> :curs:y<X>p <NR1> :cursor:y<X>position? :curs:y<X>p?			
Parameter	<X>	Cursor 1 or 2	<NR1>	Cursor position 1 – 199 (-4div – 4div)
	1	Cursor Y1		
	2	Cursor Y2		
! CAUTION: The set data format is <NR1> as follows. 1:-4div(under),100:0div(center),199:4div(upper)				
! CAUTION: The returned data format is <NR3> as follows.CH1, CH2, Math (CH1±CH2):voltage/current(V/A) Math (FFT): decibel (dB)				
Example	:cursor:ydisplay 1	Puts the vertical cursor Y1 on the center position.		
	:cursor:y1position 100			
	:channel:math 3	Returns the Y1 cursor position as 2.5dB in the		
	:cursor:y1position? → 2.500E+00	Math FFT mode.		

3-6-3.:CURSor:<X>DELta

→ **Query**

Description	Returns the distance between two horizontal (X axis) or vertical (Y axis) cursors. Same as: Cursor key → F5 (X-Y) → F4	
Syntax	< Long >	< Short >
	:cursor:<X>delta?	:curs:<X>del?
Parameter	<X>	Horizontal or vertical cursor
	x	Horizontal cursor (X axis)
	y	Vertical cursor (Y axis)
CAUTION:		The returned data format is <NR3> as follows. CH1, CH2, Math (CH1±CH2): time (s) for horizontal cursor, voltage (V) for vertical cursor Math (FFT): frequency (Hz) for horizontal cursor, decibel (dB) for vertical cursor
Example	:channel:math 3 :cursor:xdisplay 1 :cursor:xdelta? → 2.500E+03	Returns the frequency (2500Hz) between the two horizontal cursors in the Math FFT mode.
	:channel:math 3 :cursor:ydisplay 1 :cursor:ydelta? → 2.500E+00	Returns the decibel (2.5dB) between the two vertical cursors in the Math FFT mode.

3-6-4.:CURSor:<X>DISplay

 Set →

Description	Turns the horizontal or vertical cursors on/off. Same as: Cursor key			
Syntax	< Long > < Short > :cursor:y<X>display :curs:y<X>dis <Boolean> <Boolean>			
Parameter	<X>	X or Y cursor	<NR1>	Cursor on/off
	x	X (horizontal)	0	Off
	y	Y (vertical)	1	On
Example	:cursor:ydisplay 1		Turn Y cursor on.	

3-6-5.:CURSor:SOURce


 Set →
→  Query

Description	Selects or returns the cursor source channel. Same as: Cursor key →F1 (Source)			
Syntax	< Long > < Short > :cursor:source <NR1> :curs:sour <NR1> :cursor:source? :curs:sour?			
Parameter	<NR1>	Cursor source channel		
	1	Channel 1		
	2	Channel 2		
	3	Math result		
Example	:cursor:source 2		Selects Channel 2 as the cursor source.	

3-7.Display Command

3-7-1. :DISPlay:ACCumulate.....	23
3-7-2. :DISPlay:CONTrast.....	24
3-7-3. :DISPlay:GRATicule.....	24
3-7-4. :DISPlay:WAVeform.....	25
3-7-5. :REFResh	25

3-7-1.:DISPlay:ACCumulate



Description Turns the display accumulate mode on/off or returns its status.


Same as: Display key → F2

Syntax	< Long >	< Short >
	:display:accumulate <Boolean>	:disp:acc <Boolean>
	:display:accumulate?	:disp:acc?

Parameter	<NR1>	Display accumulation
	0	Off
	1	On


Example	:display:accumulate 1	Turns on the accumulation.
---------	-----------------------	----------------------------

3-7-2.:DISPlay:CONTrast




Description	Sets or returns the display contrast level. Same as: Display key → F4	
Syntax	< Long >	< Short >
	:display:contrast <NR1>	:disp:cont <NR1>
	:display:contrast?	:disp:cont?
Parameter	<NR1>	Display contrast 0 ~ 20 Lowest (0) to the Highest (20)
Example	:display:contrast 10	Sets the display contrast to the middle (10).

3-7-3.:DISPlay:GRATicule



Description	Sets or returns the display grid type. Same as: Display key → F5	
Syntax	< Long >	< Short >
	:display:graticule <NR1>	:disp:grat <NR1>
	:display:graticule?	:disp:grat?
Parameter	<NR1>	Grid type 0 Full mode 2 Grid type 1 Cross mode 2 Frame mode
Example	:display:graticule 0	Selects the full grid.

3-7-4.:DISPlay:WAVeform



Description	Sets or returns the display waveform type. Same as: Display key → F1	
Syntax	< Long >	< Short >
	:display:waveform <NR1>	:disp:wav <NR1>
	:display:waveform?	:disp:wav?
Parameter	<NR1>	Display waveform type
	0	Vectors
	1	Dots
Example	:display:waveform 0	Selects the vectors waveform.

3-7-5.:REFRresh



Description	Erases the existing waveform and draws a new one. Same as: Display key → F3	
Syntax	< Long >	< Short >
	:refresh	:refr

3-8.Measure Command

3-8-1. :MEASure:FALL	27
3-8-2. :MEASure:FOVShoot	27
3-8-3. :MEASure:FPReshoot	28
3-8-4. :MEASure:FREQuency	28
3-8-5. :MEASure:NWIDth	29
3-8-6. :MEASure:PDUTy	29
3-8-7. :MEASure:PERiod	30
3-8-8. :MEASure:PWIth	30
3-8-9. :MEASure:RISe	31
3-8-10. :MEASURE:ROVShoot	31
3-8-11. :MEASURE:RPReshoot	32
3-8-12. :MEASURE:SOURce	32
3-8-13. :MEASURE:VAMPtitude	33
3-8-14. :MEASURE:VAverage	33
3-8-15. :MEASURE:VHI	34
3-8-16. :MEASURE:VLO	34
3-8-17. :MEASURE:VMAX	35
3-8-18. :MEASURE:VMIN	35
3-8-19. :MEASURE:VPP	36
3-8-20. :MEASURE:VRMS	36

3-8-1.:MEASure:FALL

→Query

Description	Returns the fall time measurement result. Same as: Measure key → F1~F5 → F3 (Fall Time)	
Syntax	< Long >	< Short >
	:measure:fall?	:meas:fall?
Returns	<NR3> Unit: s	
 CAUTION:	Before using this command, select the measurement channel. See the example below.	
Example	:measure:source 1 :measure:fall?	Selects Channel 1, and then measures the fall time.

3-8-2.:MEASure:FOVShoot

→Query

Description	Returns the fall overshoot ratio for the waveform amplitude. Same as: Measure key → F1 ~ F5 → F3 (FOVShoot)	
Syntax	< Long >	< Short >
	:measure:fovshoot?	:meas:fovs?
Returns	<NR2> with % sign	
 CAUTION:	Before using this command, select the measurement channel. See the example below.	
Example	:measure:source 1 :measure:fovshoot?	Selects Channel 1, and then measures the fall overshoot ratio.

3-8-3.:MEASure:FPReShoot

→(Query)

Description	Returns fall preshoot ratio for the waveform amplitude. Same as: Measure key → F1 ~ F5 → F3 (FPREShoot)	
Syntax	< Long > :measure:fpshoot?	< Short > :meas:fpr?
Returns	<NR2> with % sign	
 CAUTION:	Before using this command, select the measurement channel. See the example below.	
Example	:measure:source 1 :measure:fpshoot?	Selects Channel 1, and then measures the fall preshoot ratio.

3-8-4.:MEASure:FREQuency

→(Query)

Description	Returns the frequency value. Same as: Measure key → F1~F5 → F3 (Frequency)	
Syntax	< Long > :measure:frequency?	< Short > :meas:freq?
Returns	<NR3> Unit: Hz	
 CAUTION:	Before using this command, select the measurement channel. See the example below.	
Example	:measure:source 1 :measure:frequency?	Selects Channel 1, and then measures the frequency.

3-8-5.:MEASure:NWIDth

→Query

Description	Returns the first negative pulse width timing. Same as: Measure key → F1~F5 → F3 (-Width)	
Syntax	< Long >	< Short > :measure:nwidth? :meas:nwid?
Returns	<NR3> Unit :s	
Example	:measure:source 1 :measure:nwidth?	Selects Channel 1, and then measures the negative pulse width.
! CAUTION: Before using this command, select the measurement channel. See the example below.		

3-8-6.:MEASure:PDUTy

→Query

Description	Returns the positive duty cycle ratio. Same as: Measure key → F1~F5 → F3 (DutyCycle)	
Syntax	< Long >	< Short > :measure:pduty? :meas:pdu?
Returns	<NR2> with % sign	
Example	:measure:source 1 :measure:pduty?	Selects Channel 1, and then measures the positive duty cycle.
! CAUTION: Before using this command, select the measurement channel. See the example below.		

3-8-7.:MEASure:PERiod

→ **Query**

Description	Returns the period. Same as: Measure key → F1 ~ F5 → F3 (Period)	
Syntax	< Long > :measure:period?	< Short > :meas:per?
Returns	<NR3> Unit: s	
Example	:measure:source 1 :measure:period?	Selects Channel 1, and then measures the period.
! CAUTION: Before using this command, select the measurement channel. See the example below.		

3-8-8.:MEASure:PWidth

→ **Query**

Description	Returns the first positive pulse width. Same as: Measure key → F1 ~ F5 → F3 (+Width)	
Syntax	< Long > :measure:pwidth?	< Short > :meas:pwid?
Returns	<NR3> Unit: s	
Example	:measure:source 1 :measure:pwidth?	Selects Channel 1, and then measures the positive pulse width.
! CAUTION: Before using this command, select the measurement channel. See the example below.		

3-8-9.:MEASure:RISe

→Query

Description	Returns the rise time measurement result. Same as: Measure key → F1~F5 → F3 (RiseTime)	
Syntax	< Long >	< Short >
	:measure:rise?	:meas:ris?
Returns	<NR3>	Unit: s
 CAUTION:	Before using this command, select the measurement channel. See the example below.	
Example	:measure:source 1 :measure:rise?	Selects Channel 1, and then measures the rise time.

3-8-10.:MEASure:ROVShoot

→Query

Description	Returns rise overshoot ratio for the waveform amplitude in percentage. Same as: Measure key → F1 ~ F5 → F3 (ROVShoot)	
Syntax	< Long >	< Short >
	:measure:rovshoot?	:meas:rovs?
Returns	<NR2> with % sign	
 CAUTION:	Before using this command, select the measurement channel. See the example below.	
Example	:measure:source 1 :measure:rovshoot?	Selects Channel 1, and then measures the rise overshoot ratio.

3-8-11.:MEASure:RPReshoot

→Query

Description	Returns rise preshoot ratio for the waveform amplitude in percentage.	
	Same as: Measure key → F1 ~ F5 → F3 (RPReshoot)	

Syntax	< Long >	< Short >
	:measure:rpreshoot?	:meas:rpr?

Returns	<NR2> with % sign	
---------	-------------------	--

! CAUTION: Before using this command, select the measurement channel. See the example below.

Example	:measure:source 1	Selects Channel 1,
	:measure:rpreshoot?	and then measures the rise preshoot ratio.

3-8-12.:MEASure:SOURce

Set →
→Query

Description	Selects the measurement channel.	
-------------	----------------------------------	--

Syntax	< Long >	< Short >
	:measure:source <NR1>	:meas:sour <NR1>
	:measure:source?	:meas:sour?

Parameter	<NR1>	
	1 / 2	Channel 1/2

Example	:measure:source 1	Selects Channel 1,
	:measure:rise?	and then measures the rise time.

3-8-13.:MEASure:VAMplitude

→ **Query**

Description	Returns the voltage difference between the global high voltage and the global low voltage. Same as: Measure key → F1 ~ F5 → F3 (Vamp)	
Syntax	< Long >	< Short >
	:measure:vamplitude?	:meas:vamp?
Returns	<NR3>	Unit: V



CAUTION: Before using this command, select the measurement channel. See the example below.

Example	:measure:source 1 :measure:vamplitude?	Selects Channel 1, and then measures the Voltage amplitude.
---------	---	---

3-8-14.:MEASure:VAverage

→ **Query**

Description	Returns the average voltage. Same as: Measure key → F1 ~ F5 → F3 (Vav)	
Syntax	< Long >	< Short >
	:measure:vaverage?	:meas:vav?
Returns	<NR3>	Unit: V



CAUTION: Before using this command, select the measurement channel. See the example below.

Example	:measure:source 1 :measure:vaverage?	Selects Channel 1, and then measures the average Voltage.
---------	---	---

3-8-15.:MEASure:VHI

→Query

Description	Returns the global high voltage. Same as: Measure key → F1 ~ F5 → F3 (Vhi)	
Syntax	< Long > :measure:vhi?	< Short > :meas:vhi?
Returns	<NR3> Unit: V	
 CAUTION:	Before using this command, select the measurement channel. See the example below.	
Example	:measure:source 1 :measure:vhi?	Selects Channel 1, and then measures the global high Voltage.

3-8-16.:MEASure:VLO

→Query

Description	Returns the global low voltage. Same as: Measure key → F1 ~ F5 → F3 (Vlo)	
Syntax	< Long > :measure:vlo?	< Short > :meas:vlo?
Returns	<NR3> Unit: V	
 CAUTION:	Before using this command, select the measurement channel. See the example below.	
Example	:measure:source 1 :measure:vlo?	Selects Channel 1, and then measures the global low Voltage.

3-8-17.:MEASure:VMAX

→Query

Description	Returns the maximum amplitude. Same as: Measure key → F1 ~ F5 → F3 (Vmax)	
Syntax	< Long >	< Short > :measure:vmax? :meas:vmax?
Returns	<NR3>	Unit: V
Example	:measure:source 1 :measure:vmax?	Selects Channel 1, and then measures the maximum amplitude.
! CAUTION: Before using this command, select the measurement channel. See the example below.		

3-8-18.:MEASure:VMIN

→Query

Description	Returns the minimum amplitude. Same as: Measure key → F1 ~ F5 → F3 (Vmin)	
Syntax	< Long >	< Short > :measure:vmin? :meas:vmin?
Returns	<NR3>	Unit: V
Example	:measure:source 1 :measure:vmin?	Selects Channel 1, and then measures the minimum amplitude.
! CAUTION: Before using this command, select the measurement channel. See the example below.		

3-8-19.:MEASure:VPP

→Query

Description	Returns the peak-to-peak amplitude (difference between maximum and minimum amplitude). Same as: Measure key → F1 ~ F5 → F3 (Vpp)	
Syntax	< Long > :measure:vpp?	< Short > :meas:vpp?
Returns	<NR3> Unit: V	
Example	:measure:source 1 :measure:vpp?	Selects Channel 1, and then measures the peak-to-peak amplitude.

3-8-20.:MEASure:VRMS

→Query

Description	Returns the root-mean-square voltage. Same as: Measure key → F1 ~ F5 → F3 (Vrms)	
Syntax	< Long > :measure:vrms?	< Short > :meas:vrms?
Returns	<NR3> Unit: V	
Example	:measure:source 1 :measure:vrms?	Selects Channel 1, and then measures the root mean square voltage.

3-9.Go No-Go Command


3-9-1. :GONogo:CLEar.....	37
3-9-2. :GONogo:EXECute	38
3-9-3. :GONogo:FUNCTION	38
3-9-4. :GONogo:NGCount?.....	39
3-9-5. :GONogo:NGDefine	39
3-9-6. :GONogo:SOURce.....	40
3-9-7. :GONogo:VIOLation.....	40
3-9-8. :TEMPplate:MODe	41
3-9-9. :TEMPplate:MAX	42
3-9-10. :TEMPplate:MIN.....	43
3-9-11. :TEMPplate:POSition:MAX	44
3-9-12. :TEMPplate:POSition:MIN	45
3-9-13. :TEMPplate:SAVE:MAXimum	46
3-9-14. :TEMPplate:SAVE:MINimum.....	46
3-9-15. :TEMPplate:TOLERance	47
3-9-16. :TEMPplate:SAVE:AUTo.....	48

3-9-1.:GONogo:CLEar

 Set →


Description	Clears the Go No-Go test result ratio. This is the equivalent to clearing the “failed” to “total tests” result ratio as shown in the Go-NoGo menu. Same as: Utility key → More (F5) → Go-NoGo Menu(F1)→Ratio:(F5).	
Note	Before any Go-NoGo command can be used, please use the :GONogo:FUNCTION 1 command to initialize the oscilloscope.	
Syntax	< Long > :GONogo:CLEar	< Short > :GON:CLE

3-9-2.:GONogo:EXECute



Description	Starts or stops the Go-NoGo testing. Same as: Utility key → More (F5) → Go-NoGo Menu(F1)→Go-NoGo(F4).	
Note	Before any Go-NoGo command can be used, please use the :GONogo:FUNCTION 1 command to initialize the oscilloscope.	
Syntax	< Long > :GONogo:EXECute {0 1} :GONogo:EXECute?	< Short > :GON:EXEC {0 1} :GON:EXEC?
Parameter/ Return parameter	0 1	Off. Stop Go-NoGo testing. On. Start Go-NoGo testing.
Example	:GON:EXEC 0	Turn Go-NoGo off.

3-9-3.:GONogo:FUNCTION



Description	Initializes the oscilloscope for the Go-NoGo mode. This command must be used to initialize the oscilloscope for Go-NoGo mode before any Go-NoGo commands can be executed. To exit from Go-NoGo mode, use this function to un-initialize Go-NoGo mode.	
Syntax	< Long > :GONogo:FUNCTION {0 1} :GONogo:FUNCTION?	< Short > :GON:FUNC {0 1} :GON:FUNC ?
Parameter/ Return parameter	0 1	Un-initialize the oscilloscope from Go-NoGo mode. Initialize the oscilloscope for Go-NoGo mode.
Example	:GON:FUNC 1	Initialize the scope.

3-9-4.:GONogo:NGCount?

→Query


Description	Returns the test result count ratio (failed count, total count).	
Syntax	< Long >	< Short >
	:GON:NGC?	:GON:NGC?
Return parameter	<NR1>, <NR1>	<failed count>,<total count>
Example	:GON:NGC? >2,128	2 fails from 128 Go-NoGo tests.

3-9-5.:GONogo:NGDefine

Set →
→Query


Description	Sets or queries the Go-NoGo boundary template conditions.	
Note	Before any Go-NoGo command can be used, please use the :GONogo:FUNCTION 1 command to initialize the oscilloscope.	
Syntax	< Long >	< Short >
	:GONogo:NGDefine {0 1}	:GON:NGD {0 1}
	:GONogo:NGDefine?	:GON:NGD
Parameter/ Return parameter	0	No-Go when the waveform doesn't exceed the boundary template.
	1	No-Go when the waveform exceeds the boundary template.
Example	:GON:NGD 1	NoGo conditions set to when outside template.

3-9-6.:GONogo:SOURce




Description	Sets the Go-NoGo channel source.	
Note	Before any Go-NoGo command can be used, please use the :GONogo:FUNCTION 1 command to initialize the oscilloscope.	
Syntax	< Long >	< Short >
	:GONogo:SOURce {1 2}	:GON:SOUR {1 2}
	:GONogo:SOURce?	:GON:SOUR?
Parameter/ Return parameter	1	Sets the source to channel 1
	2	Sets the source to channel 2
Example	:GON:SOUR 1	Sets the source to channel 1.

3-9-7.:GONogo:VIOLation




Description	Sets or queries the Go-NoGo violation conditions.	
Note	Before any Go-NoGo command can be used, please use the :GONogo:FUNCTION 1 command to initialize the oscilloscope.	
Syntax	< Long >	< Short >
	:GONogo:VIOLation {0 1}	:GON:VIOL {0 1}
	:GONogo:VIOLation?	:GON:VIOL?
Parameter/ Return parameter	0	Violation condition = "Continue"
	1	Violation condition = "Stop"
Example	:GON:VIOL 1	Sets the violation condition to "Continue".

3-9-8.:TEMPlate:MODe




Description	Sets or queries the Go-NoGo template mode. When Auto mode is selected, CH1 or CH2 are used as the template source. When Normal mode is selected, the template source can be selected from internal memory (W1~W15, RefA or RefB).							
Note	Before any Go-NoGo command can be used, please use the :GONogo:FUNCTION 1 command to initialize the oscilloscope.							
Syntax	<table><tr><td>< Long ></td><td>< Short ></td></tr><tr><td>:TEMPlate:MODe {0 1}</td><td>:TEMP:MOD {0 1}</td></tr><tr><td>:TEMPlate:MODe?</td><td>:TEMP:MOD?</td></tr></table>		< Long >	< Short >	:TEMPlate:MODe {0 1}	:TEMP:MOD {0 1}	:TEMPlate:MODe?	:TEMP:MOD?
< Long >	< Short >							
:TEMPlate:MODe {0 1}	:TEMP:MOD {0 1}							
:TEMPlate:MODe?	:TEMP:MOD?							
Parameter/ Return parameter	0	Select Normal template mode.						
	1	Select Auto template mode.						
Example	:TEMP:MOD 1	Set to Auto mode.						

3-9-9.:TEMPlate:MAX




Description	Sets or queries the template used for the MAX boundary (W1~W15, RefA).	
Note	<p>A template can only be defined for the MAX or MIN template, not both.</p> <p>Before this command can be used, please set the template mode to normal using the :TEMPlate:MODe 0 command.</p> <p>Before any Go-NoGo command can be used, please use the :GONogo:FUNCTION 1 command to initialize the oscilloscope.</p>	
Syntax	< Long >	< Short >
	:TEMPlate:MAX <NR1>	:TEMP:MAX <NR1>
	:TEMPlate:MAX?	:TEMP:MAX?
Parameter/ Return parameter	0	Set RefA as the MAX template.
	1~15	Set W1 ~ W15 as the MAX template
Example	:TEMP:MAX? >1	RefA is the template.

3-9-10.:TEMPlate:MIN



Description	Sets or queries the template used for the MIN boundary (W1~W15, RefB).	
Note	<p>A template can only be defined for the MAX or MIN template, not both.</p> <p>Before this command can be used, please set the template mode to normal using the :TEMPlate:MODe 0 command.</p> <p>Before any Go-NoGo command can be used, please use the :GONogo:FUNCTION 1 command to initialize the oscilloscope.</p>	
Syntax	< Long >	< Short >
	:TEMPlate:MIN <NR1>	:TEMP:MIN <NR1>
	:TEMPlate:MIN?	:TEMP:MIN?
Parameter/ Return parameter	0	Set RefB as the MIN template.
	1~15	Set W1 ~ W15 as the MIN template
Example	:TEMP :MIN ? >1	RefB is the template.

3-9-11.:TEMPlate:POSIon:MAX



Description Sets and queries the position of the MAX template in grid divisions. 1 grid division = 25 on-screen pixels.

Note This command will not alter the position of the waveform (RefA, W1~15) in memory, unless the template is saved with the :TEMPlate:SAVe :MAXimum command.

Before this command can be used, please set the template mode to normal using the :TEMPlate:MODe 0 command.


Before any Go-NoGo command can be used, please use the :GONogo:FUNCtion 1 command to initialize the oscilloscope.

Syntax	< Long >	< Short >
	:TEMPlate:POSIon:MAX <NR2>	:TEMP:POS:MAX <NR2>
	:TEMP:POS:MAX?	:TEMP:POS:MAX?

Parameter/ Return parameter	<NR2>	-12.00 ~ 12.00 Div. 0 represents the center division.
--	--------------------	---

Example	:TEMP:POS:MAX 2.00	Sets the template to the 2 nd grid division above the center division.
----------------	--------------------	---

3-9-12.:TEMPlate:POSIon:MIN



Description	Sets and queries the position of the MIN template in grid divisions. 1 grid division = 25 on-screen pixels.	
Note	<p>This command will not alter the position of the waveform (RefA, W1~15) in memory, unless the template is saved with the :TEMPlate:SAVe :MINimum command.</p> <p>Before this command can be used, please set the template mode to normal using the :TEMPlate:MODe 0 command.</p> <p>Before any Go-NoGo command can be used, please use the :GONogo:FUNCtion 1 command to initialize the oscilloscope.</p>	
Syntax	< Long >	< Short >
	:TEMPlate:POSIon:MIN <NR2>	:TEMP:POS:MIN <NR2>
	:TEMP:POS:MIN?	:TEMP:POS:MIN?
Parameter/ Return parameter	<NR2>	-12.00 ~ 12.00 Div. 0 represents the center division.
Example	:TEMP:POS:MIN 2.00	Sets the template to the 2 nd grid division above the center division.

3-9-13.:TEMPlate:SAVe:MAXimum

 Set →


Description	Saves the maximum template. Same as: Utility key → More (F5) → Go-NoGo Menu(F1)→Template Edit(F1)→Save & Create(F4).
Note	Before this command can be used, please set the template mode to normal using the :TEMPlate:MODE 0 command. Before any Go-NoGo command can be used, please use the :GONogo:FUNCTION 1 command to initialize the oscilloscope.
Syntax	< Long > < Short > :TEMPlate:SAVe:MAXimum :TEMP:SAV:MAX

3-9-14.:TEMPlate:SAVe:MINimum

 Set →

Description	Saves the minimum template. Same as: Utility key → More (F5) → Go-NoGo Menu(F1)→Template Edit(F1)→Save & Create(F4).
Note	Before this command can be used, please set the template mode to normal using the :TEMPlate:MODE 0 command. Before any Go-NoGo command can be used, please use the :GONogo:FUNCTION 1 command to initialize the oscilloscope.
Syntax	< Long > < Short > :TEMPlate:SAVe:MINimum :TEMP:SAV:MIN

3-9-15.:TEMPlate:TOlerance



Description Sets or queries the tolerance (as a percentage) of the auto template.

Note Before this command can be used, please set the template mode to auto using the :TEMPlate:MODe 1 command.
Before any Go-NoGo command can be used, please use the :GONogo:FUNCTION 1 command to initialize the oscilloscope.

Syntax < Long > < Short >
:TEMPlate:TOlerance :TEMP:TOL <NR2>
<NR2> :TEMP:TOL?
:TEMPlate:TOlerance?

Parameter/
Return
parameter <NR2> 0.4 ~ 40.0 (0.4% ~ 40%).

Example :TEMP:TOL 10 Sets the tolerance to 10%.

3-9-16.:TEMPlate:SAVe:AUTo


 Set →

Description	Saves the auto template. Same as: Utility key → More (F5) → Go-NoGo Menu(F1)→Template Edit(F1)→Save & Create(F4).	
Note	<p>Before this command can be used, please set the template mode to auto using the :TEMPlate:MODe 1 command.</p> <p>Before any Go-NoGo command can be used, please use the :GONogo:FUNCTION 1 command to initialize the oscilloscope.</p>	
Syntax	< Long > :TEMPlate:SAVe:AUTo	< Short > :TEMP:SAV:AUT

3-10.Data Logging Command


3-10-1. :DATALOG:STATE	49
3-10-2. :DATALOG:SOURce.....	49
3-10-3. :DATALOG:SAVE.....	50
3-10-4. :DATALOG:INTerval	50
3-10-5. :DATALOG:DURation	51

3-10-1.:DATALOG:STATE




Description	Turns the datalogging function on/off. Same as: Utility key → More (F5) → Data Logging Menu(F3)→Data Logging (F1).	
Syntax	< Long > :DATALOG:STATE {0 1} :DATALOG:STATE? :DATALOG:STATE?	< Short > :DATALOG:STATE {0 1} :DATALOG:STATE?
Parameter/ Return parameter	0 1	Off. Stop data logging function. On. Start data logging function.
Example	:DATALOG:STATE 1	Turn data logging on.

3-10-2.:DATALOG:SOURce




Description	Sets or queries the data logging source channel.	
Syntax	< Long > :DATALOG:SOURce{1 2} :DATALOG:SOURce?	< Short > :DATALOG:SOUR{1 2} :DATALOG:SOUR?
Parameter/ Return parameter	1 2	Sets CH1 as the source channel Sets CH2 as the source channel
Example	:DATALOG:SOUR 1	Set source as CH1.

3-10-3.:DATALOG:SAVe




Description	Sets the save type as waveform or image.					
Syntax	< Long >	< Short >				
	:DATALOG:SAVe {0 1}	:DATALOG:SAV {0 1}				
	:DATALOG:SAVe?	:DATALOG:SAV?				
Parameter/ Return parameter	<table><tr><td>0</td><td>Save as image</td></tr><tr><td>1</td><td>Save as waveform</td></tr></table>		0	Save as image	1	Save as waveform
0	Save as image					
1	Save as waveform					
Example	:DATALOG:SAVe 1	Set the save type to waveform.				

3-10-4.:DATALOG:INTerval



Description	Sets or queries the interval time between each recording.			
Syntax	< Long >	< Short >		
	:DATALOG:INTerval <NR1>	:DATALOG:INT <NR1>		
	:DATALOG:INTerval?	:DATALOG:INT?		
Parameter/ Return parameter	<table><tr><td><NR1></td><td>Discrete time intervals in seconds: {2 3 4 5 10 20 30 60 120 300 600 1200 1800}</td></tr></table>		<NR1>	Discrete time intervals in seconds: {2 3 4 5 10 20 30 60 120 300 600 1200 1800}
<NR1>	Discrete time intervals in seconds: {2 3 4 5 10 20 30 60 120 300 600 1200 1800}			
Example	:DATALOG:INT 2	Sets the interval time to 2 seconds.		

3-10-5.:DATALOG:DURation



Description	Sets or queries the duration time of each recording.	
Syntax	< Long >	< Short >
	:DATALOG:DURation <NR1>	:DATALOG:DUR <NR1>
	:DATALOG:DURation?	:DATALOG:DUR?
Parameter/ Return parameter	<NR1> Discrete recording time in minutes: {5 10 15 20 25 30 60 90 120 150 180 210 240 270 300 330 360 390 420 450 480 510 540 570 600 1200 1800 2400 3000 3600 4200 4800 5400 6000}	
Example	:DATALOG:DUR 5	Sets the recording time to 5 minutes.

3-11.Save/Recall Command

3-11-1. :MEMORY<X>:RECall:SETUp	52
3-11-2. :MEMORY<X>:RECall:WAVeform.....	53
3-11-3. :MEMORY<X>:SAVe:SETUp	53
3-11-4. :MEMORY<X>:SAVe:WAVeform.....	54
3-11-5. *RCL	54
3-11-6. :REF<X>:DISPlay	55
3-11-7. :REF<X>:LOCate	55
3-11-8. :REF<X>:SAVe	56
3-11-9. *SAV	56

3-11-1.:MEMORY<X>:RECall:SETUp

 Set →

Description	Recalls a panel setting from the internal memory. Same as: Save/Recall key (recall) → F2				
Syntax	< Long >	< Short >			
	:memory<x>:recall:setup	:mem<x>:rec:set			
Parameter	<X> 1 ~ 15	Internal memory S1 ~ S15			
Example	:memory1:recall:setup Recalls the settings from the internal memory S1.				

3-11-2.:MEMory<X>:RECall:WAveform

Set →

Description	Recalls a waveform from the internal memory and saves it to a reference waveform. Same as: Save/Recall key (recall) → F3		
Syntax	< Long > < Short > :memory<x>:recall:waveform :mem<x>:rec:wav <NR1> <NR1>		
Parameter	<X>	Internal memory	
	1 ~ 15	W1 ~ W15	
	<NR1>	Reference waveform	
	1, 2	RefA, RefB	
Example	:memory1:recall:wavefor m 1	Recalls a waveform from the internal memory W1 and saves it to the reference waveform A.	

3-11-3.:MEMory<X>:SAVe:SETUp

Set →

Description	Saves the current panel settings to an internal memory. Same as: Save/Recall key (save) → F1		
Syntax	< Long > < Short > :memory<x>:save:setup :mem<x>:sav:set		
Parameter	<X>	Internal memory	
	1 ~ 15	S1 ~ S15	
Example	:memory1:save:setup	Save the current panel settings to the memory S1.	

3-11-4.:MEMory<X>:SAVe:WAveform

 Set →


Description	Saves a reference waveform to the internal memory. Same as: Save/Recall key (save) → F2																			
Syntax	< Long >	< Short >																		
	:memory<x>:save:waveform <NR1>	:mem<x>:sav:wav <NR1>																		
Parameter	<table><tr><td><X></td><td colspan="2">Internal memory</td></tr><tr><td>1 ~ 15</td><td colspan="2">W1 ~ W15</td></tr><tr><td><NR1></td><td colspan="2">Reference waveform</td></tr><tr><td>1</td><td>CH1</td><td>2 CH2</td></tr><tr><td>3</td><td>Math</td><td>4 RefA</td></tr><tr><td>5</td><td>RefB</td><td></td></tr></table>		<X>	Internal memory		1 ~ 15	W1 ~ W15		<NR1>	Reference waveform		1	CH1	2 CH2	3	Math	4 RefA	5	RefB	
<X>	Internal memory																			
1 ~ 15	W1 ~ W15																			
<NR1>	Reference waveform																			
1	CH1	2 CH2																		
3	Math	4 RefA																		
5	RefB																			
Example	:memory1:save:waveform 1	Saves the reference waveform A to the internal memory W1.																		

3-11-5.*RCL

 Set →


Description	Recalls a set of panel setting from one of the fifteen internal memories, S1 to S15. Same as: Save/Recall key (recall) → F3	
Syntax	*rcl <NR1>	
Parameter	<NR1>	Settings
	1 to 15	S1 to S15
Example	*rcl 1	Recalls the panel settings from S1.

3-11-6.:REF<X>:DISPlay



Description	Recalls a reference waveform into the display or returns its status. Same as: Save/Recall key (recall) → F5 → F2 or F3			
Syntax	< Long > < Short > :ref<x>:display <Boolean> :ref<x>disp <Boolean> :ref<x>:display? :ref<x>disp?			
Parameter	<X>	Reference	<Boolean>	Reference on/off
	1	A	0	Off
	2	B	1	On
Example	:ref1:display 1 Turns on the reference waveform A.			

3-11-7.:REF<X>:LOCate



Description	Moves or returns the position of a reference waveform. Same as: Save/Recall key → F5 → Variable knob Value of position is; 0 as display center, 25 per 1div.			
Syntax	< Long > < Short > :ref<x>:locate <NR1> :ref<x>:loc <NR1> :ref<x>:locate? :ref<x>:loc?			
Parameter	<X>	Reference	<NR1>	Position
	1	A	-100 to +100	
	2	B		
 CAUTION:	Before using this command, turn on a reference waveform. See the example below.			
Example	:ref1:display 1 Turns on the reference waveform A and move it to ±0 position. :ref1:locate 0			

3-11-8.:REF<X>:SAVe

 Set →

Description	Saves an input signal as a reference waveform. Same as: Save/Recall key (save) → F2 → F2 → F3			
Syntax	< Long > < Short > :ref<x>:save <NR1> :ref<x>sav <NR1>			
Parameter	<X>	Reference	<NR1>	Source
	1	A	1	Channel 1
	2	B	2	Channel 2
			3	Math
Example	:ref1:save 1		Saves the Channel 1 signal as the reference waveform A.	

3-11-9.*SAV


 Set →

Description	Saves the current panel settings into the internal memory. Same as: Save/Recall key ↳ → F1			
Syntax	*sav			
Parameter	<NR1>	Internal memory		
	1 to 15	S1 to S15		
Example	*sav 1	Saves the current panel settings into S1.		

3-12.Time (Horizontal) Command

3-12-1. :TIMEbase:DELay	57
3-12-2. :TIMEbase:SCALE.....	58
3-12-3. :TIMEbase:SWEep.....	59
3-12-4. :TIMEbase:WINDOW:DELay	59
3-12-5. :TIMEbase:WINDOW:SCALe.....	60

3-12-1.:TIMEbase:DELay




Description Sets or returns the horizontal delay time (sec).

Unit: s

Syntax	< Long >	< Short >
	:timebase:delay <NR3>	:tim:del <NR3>
	:timebase:delay?	:tim:del?

Example	:timebase:delay 0	Sets the horizontal delay to 0 sec.
---------	-------------------	-------------------------------------


3-12-2.:TIMEbase:SCALe



Description	Selects or returns the horizontal scale. Same as: Time/div knob Unit: s/div					
Syntax	< Long > :timebase:scale <NR3> < Short > :tim:scal <NR3>					
Parameter	s/div	<NR3>	s/div	<NR3>	s/div	<NR3>
1ns	1e ⁻⁹	5us	5e ⁻⁶	25ms	25e ⁻³	
2.5ns	2.5e ⁻⁹	10us	10e ⁻⁶	50ms	50e ⁻³	
5ns	5e ⁻⁹	25us	25e ⁻⁶	100ms	100e ⁻³	
10ns	10e ⁻⁹	50us	50e ⁻⁶	250ms	250e ⁻³	
25ns	25e ⁻⁹	100us	100e ⁻⁶	500ms	500e ⁻³	
50ns	50e ⁻⁹	250us	250e ⁻⁶	1s	1	
100ns	100e ⁻⁹	500us	500e ⁻⁶	2.5s	2.5	
250ns	250e ⁻⁹	1ms	1e ⁻³	5s	5	
500ns	500e ⁻⁹	2.5ms	2.5e ⁻³	10s	10	
1us	1e ⁻⁶	5ms	5e ⁻³	25s	25	
2.5us	2.5e ⁻⁶	10ms	10e ⁻³	50s	50	


Example :timebase:scale 1 Selects 1s/div as the horizontal scale.

3-12-3.:TIMEbase:SWEep




Description	Selects or returns the horizontal sweep mode. Same as: Horizontal menu key → F1 ~ F5		
Syntax	< Long >	< Short >	
	:timebase:sweep <NR1>	:tim:swe <NR1>	
	:timebase:sweep?	:tim:swe?	
Parameter	<NR1>	Sweep mode	<NR1> Sweep mode
	0	Main timebase	1 Window
	2	Window zoom	3 Roll mode
	4	XY mode	
Example	:timebase:sweep 0	Selects the main timebase as the horizontal sweep mode.	

3-12-4.:TIMEbase:WINDOW:DELay



Description	Sets or returns the horizontal delay time of the zoomed window. Same as: Horizontal menu key → F2 (Window) → Horizontal Position knob Unit: s		
Syntax	< Long >	< Short >	
	:timebase:window:delay <NR3>	:tim:wind:del <NR3>	
Example	:timebase:window:delay 1.0e-3	Sets the delay time to 1ms.	

3-12-5.:TIMEbase:WINDOW:SCALe



Description	Sets or returns the display range (time scale) of the zoomed window. Same as: Horizontal menu key → F2 (Window) → Time/div knob Unit: s/div	
Syntax	< Long > :timebase:window:scale <NR3>	< Short > :tim:wind:scal<NR3>
Example	:timebase:window:scale 100e-9	Sets the display range of zoomed window to 100ns/div.

3-13.Trigger Command

3-13-1. :FORCe.....	61
3-13-2. :RUN	61
3-13-3. :SINGle	62
3-13-4. :STOP	62
3-13-5. *TRG	62
3-13-6. :TRIGger:COUPle	63
3-13-7. :TRIGger:FREQuency.....	63
3-13-8. :TRIGger:LEVel.....	64
3-13-9. :TRIGger:MODE.....	64
3-13-10. :TRIGger:NREJ.....	65
3-13-11. :TRIGger:PULSe:MODE	65
3-13-12. :TRIGger:PULSe:TIME.....	66
3-13-13. :TRIGger:REject.....	66
3-13-14. :TRIGger:SLOPe.....	67
3-13-15. :TRIGger:STATe	68
3-13-16. :TRIGger:SOURce	69
3-13-17. :TRIGger:TYPE	69
3-13-18. :TRIGger:VIDeo:FIELD.....	70
3-13-19. :TRIGger:VIDeo:LINE.....	71
3-13-20. :TRIGger:VIDeo:POLarity	72
3-13-21. :TRIGger:VIDeo:TYPE	72

3-13-1.:FORCe

 →

Description	Manually triggers the DCS-4605 and displays the input signals. Same as: (Trigger) Force key
Syntax	<Long format> :force <Short format> :forc

3-13-2.:RUN

 →

Description	Starts waiting for a trigger condition. Same as: Run key
Syntax	:run

3-13-3.:SINGle

 Set →

Description Selects the single trigger mode and starts waiting for a trigger condition.

Same as: (Trigger) Single key

Syntax <Long format> <Short format>
 :single :singl

3-13-4.:STOP


 Set →

Description Stops waiting for a trigger condition or acquiring waveform.

Same as: Stop key

Syntax :stop

3-13-5.*TRG


 Set →

Description Manually triggers the DCS-4605 and displays the input signals.

Same as: (Trigger) Force key

Syntax *trg

3-13-6.:TRIGger:COUPle




Description	Selects or returns the trigger coupling mode. Same as: Trigger menu key → F4 → F2							
Syntax	< Long >	< Short >						
	:trigger:couple <NR1>	:trig:coup <NR1>						
	:trigger:couple?	:trig:coup?						
Parameter	<table><tr><td><NR1></td><td>Coupling mode</td></tr><tr><td>0</td><td>AC</td></tr><tr><td>1</td><td>DC</td></tr></table>		<NR1>	Coupling mode	0	AC	1	DC
<NR1>	Coupling mode							
0	AC							
1	DC							
 CAUTION:	Before using this command, select the edge or pulse trigger. See the example below.							
Example	:trigger:type: 0 :trigger:couple 1	Selects the edge trigger and DC coupling mode.						

3-13-7.:TRIGger:FREQuency




Description	Returns the trigger frequency readout.	
Syntax	< Long >	< Short >
	:trigger:frequency?	:trig:freq?
Returns	<NR3>	Unit: Hz

3-13-8.:TRIGger:LEVel



Description	Selects or returns the trigger level. Same as: Trigger level knob Unit: V	
Syntax	< Long > :trigger:level <NR3> :trigger:level?	< Short > :trig:lev <NR3> :trig:lev?
Parameter	<NR3> Trigger level in voltage	
Example	:trigger:level 0	Sets the trigger level at ±0.

3-13-9.:TRIGger:MODE




Description	Selects or returns the trigger mode. Same as: Trigger key → F5	
Syntax	< Long > :trigger:mode <NR1> :trigger:mode?	< Short > :trig:mod <NR1> :trig:mod?
Parameter	<NR1> Trigger mode	
	1	Auto
	2	Normal

 **CAUTION:** Before using this command, select the edge or pulse trigger. See the example below.


Example	:trigger:type: 0 :trigger:mode 2	Selects the edge trigger and normal trigger mode.
---------	-------------------------------------	---

3-13-10.:TRIGger:NREJ




Description	Turns the noise rejection mode on/off. Same as: Trigger key → F4 → F4	
Syntax	< Long > :trigger:nrej <Boolean> :trigger:nrej?	< Short > :trig:nrej <Boolean> :trig:nrej?
Parameter	<Boolean>	Noise rejection mode 0 Off 1 On
! CAUTION:		Before using this command, select the edge or pulse trigger. See the example below.
Example	:trigger:type 0 :trigger:nrej 0	Selects the edge trigger and turns off the noise rejection.

3-13-11.:TRIGger:PULSe:MODE



Description	Selects the trigger mode in the pulse trigger. Same as: Trigger key → F1(Pulse) → F3			
Syntax	< Long >	< Short > :trigger:pulse:mode <NR1> :trigger:pulse:mode?		
Parameter	<NR1>	Mode 0 < 1 >	<NR1>	Mode 2 = 3 ≠
! CAUTION:		Before using this command, select the pulse trigger. See the example below.		
Example	:trigger:type 2 :trigger:pulse:mode 0	Selects the pulse trigger and < (smaller than) as the trigger mode.		

3-13-12.:TRIGger:PULSe:TIME



Description Selects the trigger pulse time(width) in the pulse trigger.

Same as: Trigger key → F1(Pulse) → F3 →

Variable knob

Unit: s


Syntax < Long > < Short >
:trigger:pulse:time <NR3> :trig:puls:tim <NR3>
:trigger:pulse:time? :trig:puls:tim?

Parameter <NR3> Trigger pulse time(width)
20e⁻⁹ ~ 10 20ns ~ 10s

! CAUTION: Before using this command, select the pulse trigger. See the example below.

Example :trigger:type 2 Selects the pulse trigger
 and sets the trigger
 pulse time as 1sec.

3-13-13.:TRIGger:REJECT



Description Selects the trigger rejection filter.

Same as: Trigger key → F4 → F3


Syntax < Long > < Short >
:trigger:reject <NR1> :trig:rej <NR1>
:trigger:reject? :trig:rej?

Parameter <NR1> Rejection filter
0 off
1 LF
2 HF

! CAUTION: Before using this command, select the edge or pulse trigger. See the example below.

Example :trigger:type 0 Selects the edge trigger
 and LF rejection filter.

3-13-14.:TRIGger:SLOPe



Description	Selects the trigger slope. Same as: Trigger key → F4 → F1	
Syntax	< Long >	< Short >
	:trigger:slope <NR1>	:trig:slop <NR1>
	:trigger:slope?	:trig:slop?
Parameter	<NR1>	Trigger slope
	0	+ (positive)
	1	- (negative)
 CAUTION:	Before using this command, select the edge or pulse trigger. See the example below.	
Example	:trigger:type 0 :trigger:slope 1	Selects the edge trigger and negative trigger slope.

3-13-15.:TRIGger:STATe

→Query

Description	Queries the present trigger state.	
Syntax	< Long > :trigger:state?	< Short > :trig:stat?
Return Parameter	<NR1>	Trigger state 0 Un-triggered 1 Triggered


**CAUTION:**

This function is designed for triggering with slow time-bases or for single shot events. This query will return 0 before the trigger point and 1 after a trigger point (if any).

However with quicker time-bases in auto mode, a periodic waveform is constantly re-sampled and thus re-triggered each time, resulting in the query returning 0 before each trigger. Therefore with quicker time bases, this will usually result in 0 being returned, even if the waveform is shown as triggered.


Example	:trigger:state? 0	Returns the current trigger state as un-triggered.
---------	----------------------	--

3-13-16.:TRIGger:SOURce




Description	Selects the trigger source channel. Same as: Trigger key → F2															
Syntax	< Long > < Short > :trigger:source <NR1> :trig:sour <NR1> :trigger:source? :trig:sour?															
Parameter	<table><tr><td><NR1></td><td>Trigger source</td><td><NR1></td><td>Trigger source</td></tr><tr><td>0</td><td>Channel 1</td><td>2</td><td>External input</td></tr><tr><td>1</td><td>Channel 2</td><td>3</td><td>Line</td></tr></table>				<NR1>	Trigger source	<NR1>	Trigger source	0	Channel 1	2	External input	1	Channel 2	3	Line
<NR1>	Trigger source	<NR1>	Trigger source													
0	Channel 1	2	External input													
1	Channel 2	3	Line													
Example	:trigger:source 0	Selects Channel 1 as the trigger source.														

3-13-17.:TRIGger:TYPE




Description	Selects the trigger type. Same as: Trigger key → F1															
Syntax	< Long > < Short > :trigger:type <NR1> :trig:typ <NR1> :trigger:type? :trig:typ?															
Parameter	<table><tr><td><NR1></td><td>Trigger type</td><td><NR1></td><td>Trigger type</td></tr><tr><td>0</td><td>Edge</td><td>2</td><td>Pulse</td></tr><tr><td>1</td><td>Video</td><td></td><td></td></tr></table>				<NR1>	Trigger type	<NR1>	Trigger type	0	Edge	2	Pulse	1	Video		
<NR1>	Trigger type	<NR1>	Trigger type													
0	Edge	2	Pulse													
1	Video															
Example	:trigger:type 0	Selects the edge trigger type.														

3-13-18.:TRIGger:VIDeo:FIELD




Description	Selects the trigger field in the video trigger. Same as: Trigger key → F1(Video) → F5		
Syntax	< Long > < Short > :trigger:video:field <NR1> :trig:vid:fiel <NR1> :trigger:video:field? :trig:vid:fiel?		
Parameter	<NR1>	Field	<NR1> Field
	0	Line	2 even
	1	odd	
 CAUTION:	Before using this command, select the video trigger. See the example below.		
Example	:trigger:type 1	Selects the video trigger and odd trigger field.	
	:trigger:video:field 1		

3-13-19.:TRIGger:VIDeo:LINE




Description	Selects the trigger field line in the video trigger. Same as: Trigger key → F1(Video) → F5 → Variable knob							
Syntax	<table><tr><td>< Long ></td><td>< Short ></td></tr><tr><td>:trigger:video:line <NR1></td><td>:trig:vid:lin <NR1></td></tr><tr><td>:trigger:video:line?</td><td>:trig:vid:lin?</td></tr></table>		< Long >	< Short >	:trigger:video:line <NR1>	:trig:vid:lin <NR1>	:trigger:video:line?	:trig:vid:lin?
< Long >	< Short >							
:trigger:video:line <NR1>	:trig:vid:lin <NR1>							
:trigger:video:line?	:trig:vid:lin?							
Parameter	<NR1> Line range 1 ~ 263 NTSC odd 1 ~ 262 NTSC even	<NR1> Line range 1 ~ 313 PAL/SECAM odd 1 ~ 312 PAL/SECAM even						
 CAUTION:	Before using this command, select the video trigger, TV standard, and odd or even trigger field. See the example below.							
Example	:trigger:type 1 :trigger:video:type 0 :trigger:video:field 1 :trigger:video:line 313	Selects the video trigger, PAL, odd field triggering, and line 313.						

3-13-20.:TRIGger:VIDeo:POLarity



Description	Selects the video trigger polarity. Same as: Trigger key → F1(Video) → F4	
Syntax	< Long > < Short > :trigger:video:polarity <NR1> :trig:vid:pol <NR1> :trigger:video:polarity? :trig:vid:pol?	
Parameter	<NR1>	Polarity
	0	Positive
	1	Negative
CAUTION:	Before using this command, select the video trigger. See the example below.	
Example	:trigger:type 1 :trigger:video:polarity 0	Selects the video trigger and positive polarity.

3-13-21.:TRIGger:VIDeo:TYPE



Description	Selects the TV standard in the video trigger. Same as: Trigger key → F1(Video) → F3	
Syntax	< Long > < Short > :trigger:video:type <NR1> :trig:vid:typ <NR1> :trigger:video:type? :trig:vid:typ?	
Parameter	<NR1> Type	<NR1> Type
	0 PAL	2 SECAM
	1 NTSC	
CAUTION:	Before using this command, select the video trigger. See the example below.	
Example	:trigger:type 1 :trigger:video:type 0	Selects the video trigger and PAL standard.



TEXIO TECHNOLOGY CORPORATION

7F Towa Fudosan Shin Yokohama Bldg., 2-18-13, Shin Yokohama, Kohoku-ku,
Yokohama, Kanagawa, 222-0033, Japan.

<http://www.texio.co.jp>

